



NOTES:

1. ALL DIMENSIONS IN MILLIMETERS
2. HPB LAYER NOT TO EXCEED 40mm IN DEPTH. DO NOT USE LIMESTONE SCREENINGS.
3. IN SANDY SOILS, BASE DEPTH TO BE 450mm DEEP.
4. CONFIRM SOIL CONDITIONS WITH A QUALIFIED SOILS ENGINEER PRIOR TO INSTALLATION OF BASE.
5. USE AN EDGE RESTRAINT ON ALL AREAS ABUTTING SOD.



## STANDARD CONSTRUCTION DETAIL

# HYDROPAVERS® PAVING

DRAWN BY: mpl

CHECKED BY: mpl

DRAWING NUMBER:

DATE: APR. 26, 2018

SCALE: 1:15